

Защита шлангов. Технические характеристики.

По вопросам продаж и поддержки обращайтесь: itd@nt-rt.ru

www.indexator.nt-rt.ru

Архангельск (8182)63-90-72
Астана (7172)727-132
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62

Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81 Магнитогорск
(3519)55-03-13 Москва
(495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73 Омск
(3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64

Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54 Сочи
(862)225-72-31 Ставрополь
(8652)20-65-13 Сургут
(3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59 Уфа
(347)229-48-12 Хабаровск
(4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93



Казахстан (7273)495-231

Киргизия (996)312-96-26-47

Таджикистан (992)427-82-92-69

Hose guard XL

Part number: 5112006



As an alternative to the standard hose guard, Indexator Rotator Systems can offer an extra robust hose guard.

- ✓ Ideal for both normal and tough environments
- ✓ Satisfies stringent demands for durability
- ✓ Robust, durable product in a single piece
- ✓ Facilitates alternative hose connection

Hose guard XL is suitable for all rotators within the GV12, GV14 and GV17 families, apart from models with the designation "-2".*

The XL guard is installed very easily using four screws and four washers. When replacing a standard hose guard with Hose guard XL, two additional screws and two washers must be installed in addition to those used for the standard hose guard.

When purchasing Hose guard XL, you are recommended to order the following components:

When replacing a standard guard:

- 1 x Hose guard XL (Art. no. 5112006)
- Additional 2 x Screw M12 (Art. no. 1016203) or
- 2 x Screw 1/2"-13 UNC (Art. no. 1019926) for US models
- 2 x Washer (Art. no. 1017326)

For new installation of Hose guard XL:

- 1 x Hose guard XL (Art. no. 5112006)
- 4 x Screw M12 (Art. no. 1016203) or
- 4 x Screw 1/2"-13 UNC (Art. no. 1019926) for US models
- 4 x Washer (Art. no. 1017326)

* Models with the "-2" designation have two connections on either side of the rotator and use two standard hose guards.

C: 240 mm	G: 90 mm	J: 37,5 mm
Ø L: 13 mm	M: 210 mm	O: 15,5 mm
RQ: 99 mm	T: 270 mm	

IR 10/12 Hose protection

Part number: 8000388





- ✓ Perfect for both normal and demanding environments
- ✓ For high standards of durability
- ✓ Robust and strong in one piece
- ✓ Enables alternative hose connection

IR 10/12 Hose protection fits the following IR 10/12 models:

- IR 10 HPL M20
- IR 10M M20
- IR 10 M20
- IR 12 L
- IR 12 X
- IR 12

Installation of the hose protection is very easy, and is done with four screws.

Requires Indexator's attachment (8000379).



C: 149 mm

G: 300 mm

T: 117 mm

IR 20/22 Hose protection

Artikelnummer: 8020000





- ✓ Perfect for both normal and demanding environments
- ✓ For high standards of durability
- ✓ Robust and strong in one piece
- ✓ Enables alternative hose connection

IR 20/22 Hose protection fits all IR 20/22 models except IR 22 X2 and IR 22 XA.

Installation of the hose protection is very easy, and is done with three screws and washers.

Requires Indexator's attachment (8000379).



A: 149 mm

C: 300 mm

G: 117 mm

T: 255 mm

XR 400 Hose Guard



Part number: 6005136



- ✓ Perfect for both normal and demanding environments
- ✓ For high standards of durability
- ✓ Robust and strong in one piece
- ✓ Enables alternative hose connection

XR 400 Hose protection fits all XR 400 models.

Installation of the hose protection is very easy, and is done with four screws and washers.



A: 168 mm

C: 440 mm

J: 8 mm

B: 254 mm

G: 110 mm

T: 275 mm

По вопросам продаж и поддержки обращайтесь: itd@nt-rt.ru

www.indexator.nt-rt.ru

Архангельск (8182)63-90-72
Астана (7172)727-132
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62

Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81 Магнитогорск
(3519)55-03-13 Москва
(495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73 Омск
(3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64

Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54 Сочи
(862)225-72-31 Ставрополь
(8652)20-65-13 Сургут
(3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59 Уфа
(347)229-48-12 Хабаровск
(4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

Казахстан (7273)495-231

Киргизия (996)312-96-26-47

Таджикистан (992)427-82-92-69